MTD NAND Driver Programming Interface

Thomas Gleixner

tglx@linutronix.de

MTD NAND Driver Programming Interface

by Thomas Gleixner

Copyright © 2004 Thomas Gleixner

This documentation is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License version 2 as published by the Free Software Foundation.
This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.
You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA
For more details see the file COPYING in the source distribution of Linux.

Table of Contents

1. Introduction **1**
2. Known Bugs And Assumptions **3**
3. Documentation hints **5**
3.1. Function identifiers [XXX] 5
3.2. Struct member identifiers [XXX] 5
4. Basic board driver **7**
4.1. Basic defines 7
4.2. Partition defines 7
4.3. Hardware control function 7
4.4. Device ready function 8
4.5. Init function 8
4.6. Exit function 10
5. Advanced board driver functions **11**
5.1. Multiple chip control 11
5.2. Hardware ECC support 12
5.2.1. Functions and constants 12
5.2.2. Hardware ECC with syndrome calculation 13
5.3. Bad block table support 13
5.3.1. Flash based tables 14
5.3.2. User defined tables 15
5.4. Spare area (auto)placement 17
5.4.1. Placement defined by fs driver 18
5.4.2. Automatic placement 18
5.4.3. User space placement selection 18
5.5. Spare area autoplacement default schemes 19
5.5.1. 256 byte pagesize 19
5.5.2. 512 byte pagesize 19
5.5.3. 2048 byte pagesize 20
6. Filesystem support **23**
7. Tools **25**
8. Constants **27**
8.1. Chip option constants 27
8.1.1. Constants for chip id table 27
8.1.2. Constants for runtime options 27
8.2. ECC selection constants 28
8.3. Hardware control related constants 28
8.4. Bad block table related constants 29

9. Structures **31**
struct nand_hw_control 31
struct nand_ecc_ctrl 32
struct nand_buffers 34
struct nand_chip 35
struct nand_flash_dev 40
struct nand_manufacturers 41
struct platform_nand_chip 42
struct platform_nand_ctrl 44
struct platform_nand_data 45
10. Public Functions Provided **47**
nand_unlock 47
nand_lock 48
nand_scan_ident 49
nand_scan_tail 50
nand_scan 50
nand_release 51
nand_scan_bbt 52
nand_default_bbt 53
__nand_calculate_ecc 54
nand_calculate_ecc 55
__nand_correct_data 56
nand_correct_data 57
11. Internal Functions Provided **59**
nand_release_device 59
nand_read_byte 59
nand_read_byte16 60
nand_read_word 61
nand_select_chip 62
nand_write_buf 63
nand_read_buf 64
nand_verify_buf 65
nand_write_buf16 66
nand_read_buf16 67
nand_verify_buf16 67
nand_block_bad 68
nand_default_block_markbad 69
nand_check_wp 70
nand_block_checkbad 71
panic_nand_wait_ready 72
nand_command 73
nand_command_lp 74

panic_nand_get_device 75
nand_get_device 76
panic_nand_wait 77
nand_wait 78
__nand_unlock 79
nand_read_page_raw 80
nand_read_page_raw_syndrome 81
nand_read_page_swecc 82
nand_read_subpage 83
nand_read_page_hwecc 84
nand_read_page_hwecc_oob_first 85
nand_read_page_syndrome 87
nand_transfer_oob 88
nand_do_read_ops 89
nand_read 89
nand_read_oob_std 91
nand_read_oob_syndrome 91
nand_write_oob_std 92
nand_write_oob_syndrome 93
nand_do_read_oob 94
nand_read_oob 95
nand_write_page_raw 96
nand_write_page_raw_syndrome 97
nand_write_page_swecc 98
nand_write_page_hwecc 99
nand_write_page_syndrome 100
nand_write_page 101
nand_fill_oob 102
nand_do_write_ops 103
panic_nand_write 104
nand_write 105
nand_do_write_oob 106
nand_write_oob 107
single_erase_cmd 108
multi_erase_cmd 109
nand_erase 110
nand_erase_nand 111
nand_sync 112
nand_block_isbad 112
nand_block_markbad 113
nand_suspend 114
nand_resume 115
check_pattern 115

check_short_pattern 116
add_marker_len 117
read_bbt 118
read_abs_bbt 119
read_abs_bbts 120
create_bbt 122
search_bbt 123
search_read_bbts 124
write_bbt 125
nand_memory_bbt 126
check_create 127
mark_bbt_region 127
verify_bbt_descr 128
nand_update_bbt 129
nand_create_default_bbt_descr 130
nand_isbad_bbt 131
12. Credits 133

Chapter 1. Introduction

The generic NAND driver supports almost all NAND and AG-AND based chips and connects them to the Memory Technology Devices (MTD) subsystem of the Linux Kernel.

This documentation is provided for developers who want to implement board drivers or filesystem drivers suitable for NAND devices.

Chapter 2. Known Bugs And Assumptions

None.

Chapter 3. Documentation hints

The function and structure docs are autogenerated. Each function and struct member has a short description which is marked with an [XXX] identifier. The following chapters explain the meaning of those identifiers.

3.1. Function identifiers [XXX]

The functions are marked with [XXX] identifiers in the short comment. The identifiers explain the usage and scope of the functions. Following identifiers are used:

- [MTD Interface]

  These functions provide the interface to the MTD kernel API. They are not replacable and provide functionality which is complete hardware independent.

- [NAND Interface]

  These functions are exported and provide the interface to the NAND kernel API.

- [GENERIC]

  Generic functions are not replacable and provide functionality which is complete hardware independent.

- [DEFAULT]

  Default functions provide hardware related functionality which is suitable for most of the implementations. These functions can be replaced by the board driver if neccecary. Those functions are called via pointers in the NAND chip description structure. The board driver can set the functions which should be replaced by board dependent functions before calling nand_scan(). If the function pointer is NULL on entry to nand_scan() then the pointer is set to the default function which is suitable for the detected chip type.

3.2. Struct member identifiers [XXX]

The struct members are marked with [XXX] identifiers in the comment. The identifiers explain the usage and scope of the members. Following identifiers are used:

- [INTERN]

These members are for NAND driver internal use only and must not be modified. Most of these values are calculated from the chip geometry information which is evaluated during nand_scan().

- [REPLACEABLE]

  Replaceable members hold hardware related functions which can be provided by the board driver. The board driver can set the functions which should be replaced by board dependent functions before calling nand_scan(). If the function pointer is NULL on entry to nand_scan() then the pointer is set to the default function which is suitable for the detected chip type.

- [BOARDSPECIFIC]

  Board specific members hold hardware related information which must be provided by the board driver. The board driver must set the function pointers and datafields before calling nand_scan().

- [OPTIONAL]

  Optional members can hold information relevant for the board driver. The generic NAND driver code does not use this information.

Chapter 4. Basic board driver

For most boards it will be sufficient to provide just the basic functions and fill out some really board dependent members in the nand chip description structure.

4.1. Basic defines

At least you have to provide a mtd structure and a storage for the ioremap'ed chip address. You can allocate the mtd structure using kmalloc or you can allocate it statically. In case of static allocation you have to allocate a nand_chip structure too.

Kmalloc based example

```
static struct mtd_info *board_mtd;
static void __iomem *baseaddr;
```

Static example

```
static struct mtd_info board_mtd;
static struct nand_chip board_chip;
static void __iomem *baseaddr;
```

4.2. Partition defines

If you want to divide your device into partitions, then define a partitioning scheme suitable to your board.

```
#define NUM_PARTITIONS 2
static struct mtd_partition partition_info[] = {
 { .name = "Flash partition 1",
   .offset =  0,
   .size =    8 * 1024 * 1024 },
 { .name = "Flash partition 2",
   .offset =  MTDPART_OFS_NEXT,
   .size =    MTDPART_SIZ_FULL },
};
```

4.3. Hardware control function

The hardware control function provides access to the control pins of the NAND chip(s). The access can be done by GPIO pins or by address lines. If you use address lines, make sure that the timing requirements are met.

GPIO based example

```
static void board_hwcontrol(struct mtd_info *mtd, int cmd)
{
 switch(cmd){
  case NAND_CTL_SETCLE: /* Set CLE pin high */ break;
  case NAND_CTL_CLRCLE: /* Set CLE pin low */ break;
  case NAND_CTL_SETALE: /* Set ALE pin high */ break;
  case NAND_CTL_CLRALE: /* Set ALE pin low */ break;
  case NAND_CTL_SETNCE: /* Set nCE pin low */ break;
  case NAND_CTL_CLRNCE: /* Set nCE pin high */ break;
 }
}
```

Address lines based example. It's assumed that the nCE pin is driven by a chip select decoder.

```
static void board_hwcontrol(struct mtd_info *mtd, int cmd)
{
 struct nand_chip *this = (struct nand_chip *) mtd->priv;
 switch(cmd){
  case NAND_CTL_SETCLE: this->IO_ADDR_W |= CLE_ADRR_BIT;  break;
  case NAND_CTL_CLRCLE: this->IO_ADDR_W &= ~CLE_ADRR_BIT; break;
  case NAND_CTL_SETALE: this->IO_ADDR_W |= ALE_ADRR_BIT;  break;
  case NAND_CTL_CLRALE: this->IO_ADDR_W &= ~ALE_ADRR_BIT; break;
 }
}
```

4.4. Device ready function

If the hardware interface has the ready busy pin of the NAND chip connected to a GPIO or other accessible I/O pin, this function is used to read back the state of the pin. The function has no arguments and should return 0, if the device is busy (R/B pin is low) and 1, if the device is ready (R/B pin is high). If the hardware interface does not give access to the ready busy pin, then the function must not be defined and the function pointer this->dev_ready is set to NULL.

4.5. Init function

The init function allocates memory and sets up all the board specific parameters and function pointers. When everything is set up nand_scan() is called. This function tries to detect and identify then chip. If a chip is found all the internal data fields are initialized accordingly. The structure(s) have to be zeroed out first and then filled with the neccecary information about the device.

```
static int __init board_init (void)
{
 struct nand_chip *this;
 int err = 0;

 /* Allocate memory for MTD device structure and private data */
 board_mtd = kzalloc(sizeof(struct mtd_info) + sizeof(struct nand_chip), 
 if (!board_mtd) {
  printk ("Unable to allocate NAND MTD device structure.\n");
  err = -ENOMEM;
  goto out;
 }

 /* map physical address */
 baseaddr = ioremap(CHIP_PHYSICAL_ADDRESS, 1024);
 if (!baseaddr) {
  printk("Ioremap to access NAND chip failed\n");
  err = -EIO;
  goto out_mtd;
 }

 /* Get pointer to private data */
 this = (struct nand_chip *) ();
 /* Link the private data with the MTD structure */
 board_mtd->priv = this;

 /* Set address of NAND IO lines */
 this->IO_ADDR_R = baseaddr;
 this->IO_ADDR_W = baseaddr;
 /* Reference hardware control function */
 this->hwcontrol = board_hwcontrol;
 /* Set command delay time, see datasheet for correct value */
 this->chip_delay = CHIP_DEPENDEND_COMMAND_DELAY;
 /* Assign the device ready function, if available */
 this->dev_ready = board_dev_ready;
 this->eccmode = NAND_ECC_SOFT;

 /* Scan to find existence of the device */
 if (nand_scan (board_mtd, 1)) {
```

```
  err = -ENXIO;
  goto out_ior;
 }

 add_mtd_partitions(board_mtd, partition_info, NUM_PARTITIONS);
 goto out;

out_ior:
 iounmap(baseaddr);
out_mtd:
 kfree (board_mtd);
out:
 return err;
}
module_init(board_init);
```

4.6. Exit function

The exit function is only neccecary if the driver is compiled as a module. It releases all resources which are held by the chip driver and unregisters the partitions in the MTD layer.

```
#ifdef MODULE
static void __exit board_cleanup (void)
{
 /* Release resources, unregister device */
 nand_release (board_mtd);

 /* unmap physical address */
 iounmap(baseaddr);

 /* Free the MTD device structure */
 kfree (board_mtd);
}
module_exit(board_cleanup);
#endif
```

Chapter 5. Advanced board driver functions

This chapter describes the advanced functionality of the NAND driver. For a list of functions which can be overridden by the board driver see the documentation of the nand_chip structure.

5.1. Multiple chip control

The nand driver can control chip arrays. Therefore the board driver must provide an own select_chip function. This function must (de)select the requested chip. The function pointer in the nand_chip structure must be set before calling nand_scan(). The maxchip parameter of nand_scan() defines the maximum number of chips to scan for. Make sure that the select_chip function can handle the requested number of chips.

The nand driver concatenates the chips to one virtual chip and provides this virtual chip to the MTD layer.

Note: The driver can only handle linear chip arrays of equally sized chips. There is no support for parallel arrays which extend the buswidth.

GPIO based example

```
static void board_select_chip (struct mtd_info *mtd, int chip)
{
 /* Deselect all chips, set all nCE pins high */
 GPIO(BOARD_NAND_NCE) |= 0xff;
 if (chip >= 0)
  GPIO(BOARD_NAND_NCE) &= ~ (1 << chip);
}
```

Address lines based example. Its assumed that the nCE pins are connected to an address decoder.

```
static void board_select_chip (struct mtd_info *mtd, int chip)
{
 struct nand_chip *this = (struct nand_chip *) mtd->priv;

 /* Deselect all chips */
 this->IO_ADDR_R &= ~BOARD_NAND_ADDR_MASK;
 this->IO_ADDR_W &= ~BOARD_NAND_ADDR_MASK;
 switch (chip) {
```

```
 case 0:
  this->IO_ADDR_R |= BOARD_NAND_ADDR_CHIP0;
  this->IO_ADDR_W |= BOARD_NAND_ADDR_CHIP0;
  break;
 ....
 case n:
  this->IO_ADDR_R |= BOARD_NAND_ADDR_CHIPn;
  this->IO_ADDR_W |= BOARD_NAND_ADDR_CHIPn;
  break;
 }
}
```

5.2. Hardware ECC support

5.2.1. Functions and constants

The nand driver supports three different types of hardware ECC.

- NAND_ECC_HW3_256

  Hardware ECC generator providing 3 bytes ECC per 256 byte.
- NAND_ECC_HW3_512

  Hardware ECC generator providing 3 bytes ECC per 512 byte.
- NAND_ECC_HW6_512

  Hardware ECC generator providing 6 bytes ECC per 512 byte.
- NAND_ECC_HW8_512

  Hardware ECC generator providing 6 bytes ECC per 512 byte.

If your hardware generator has a different functionality add it at the appropriate place in nand_base.c

The board driver must provide following functions:

- enable_hwecc

  This function is called before reading / writing to the chip. Reset or initialize the hardware generator in this function. The function is called with an argument which let you distinguish between read and write operations.
- calculate_ecc

This function is called after read / write from / to the chip. Transfer the ECC from the hardware to the buffer. If the option NAND_HWECC_SYNDROME is set then the function is only called on write. See below.

- correct_data

  In case of an ECC error this function is called for error detection and correction. Return 1 respectively 2 in case the error can be corrected. If the error is not correctable return -1. If your hardware generator matches the default algorithm of the nand_ecc software generator then use the correction function provided by nand_ecc instead of implementing duplicated code.

5.2.2. Hardware ECC with syndrome calculation

Many hardware ECC implementations provide Reed-Solomon codes and calculate an error syndrome on read. The syndrome must be converted to a standard Reed-Solomon syndrome before calling the error correction code in the generic Reed-Solomon library.

The ECC bytes must be placed immediately after the data bytes in order to make the syndrome generator work. This is contrary to the usual layout used by software ECC. The separation of data and out of band area is not longer possible. The nand driver code handles this layout and the remaining free bytes in the oob area are managed by the autoplacement code. Provide a matching oob-layout in this case. See rts_from4.c and diskonchip.c for implementation reference. In those cases we must also use bad block tables on FLASH, because the ECC layout is interferring with the bad block marker positions. See bad block table support for details.

5.3. Bad block table support

Most NAND chips mark the bad blocks at a defined position in the spare area. Those blocks must not be erased under any circumstances as the bad block information would be lost. It is possible to check the bad block mark each time when the blocks are accessed by reading the spare area of the first page in the block. This is time consuming so a bad block table is used.

The nand driver supports various types of bad block tables.

- Per device

The bad block table contains all bad block information of the device which can consist of multiple chips.

- Per chip

  A bad block table is used per chip and contains the bad block information for this particular chip.

- Fixed offset

  The bad block table is located at a fixed offset in the chip (device). This applies to various DiskOnChip devices.

- Automatic placed

  The bad block table is automatically placed and detected either at the end or at the beginning of a chip (device)

- Mirrored tables

  The bad block table is mirrored on the chip (device) to allow updates of the bad block table without data loss.

nand_scan() calls the function nand_default_bbt(). nand_default_bbt() selects appropriate default bad block table desriptors depending on the chip information which was retrieved by nand_scan().

The standard policy is scanning the device for bad blocks and build a ram based bad block table which allows faster access than always checking the bad block information on the flash chip itself.

5.3.1. Flash based tables

It may be desired or neccecary to keep a bad block table in FLASH. For AG-AND chips this is mandatory, as they have no factory marked bad blocks. They have factory marked good blocks. The marker pattern is erased when the block is erased to be reused. So in case of powerloss before writing the pattern back to the chip this block would be lost and added to the bad blocks. Therefore we scan the chip(s) when we detect them the first time for good blocks and store this information in a bad block table before erasing any of the blocks.

The blocks in which the tables are stored are procteted against accidental access by marking them bad in the memory bad block table. The bad block table management functions are allowed to circumvernt this protection.

The simplest way to activate the FLASH based bad block table support is to set the option NAND_USE_FLASH_BBT in the option field of the nand chip structure before calling nand_scan(). For AG-AND chips is this done by default. This

activates the default FLASH based bad block table functionality of the NAND driver. The default bad block table options are

- Store bad block table per chip
- Use 2 bits per block
- Automatic placement at the end of the chip
- Use mirrored tables with version numbers
- Reserve 4 blocks at the end of the chip

5.3.2. User defined tables

User defined tables are created by filling out a nand_bbt_descr structure and storing the pointer in the nand_chip structure member bbt_td before calling nand_scan(). If a mirror table is neccecary a second structure must be created and a pointer to this structure must be stored in bbt_md inside the nand_chip structure. If the bbt_md member is set to NULL then only the main table is used and no scan for the mirrored table is performed.

The most important field in the nand_bbt_descr structure is the options field. The options define most of the table properties. Use the predefined constants from nand.h to define the options.

- Number of bits per block

  The supported number of bits is 1, 2, 4, 8.
- Table per chip

  Setting the constant NAND_BBT_PERCHIP selects that a bad block table is managed for each chip in a chip array. If this option is not set then a per device bad block table is used.
- Table location is absolute

  Use the option constant NAND_BBT_ABSPAGE and define the absolute page number where the bad block table starts in the field pages. If you have selected bad block tables per chip and you have a multi chip array then the start page must be given for each chip in the chip array. Note: there is no scan for a table ident pattern performed, so the fields pattern, veroffs, offs, len can be left uninitialized
- Table location is automatically detected

  The table can either be located in the first or the last good blocks of the chip (device). Set NAND_BBT_LASTBLOCK to place the bad block table at the end

of the chip (device). The bad block tables are marked and identified by a pattern which is stored in the spare area of the first page in the block which holds the bad block table. Store a pointer to the pattern in the pattern field. Further the length of the pattern has to be stored in len and the offset in the spare area must be given in the offs member of the nand_bbt_descr structure. For mirrored bad block tables different patterns are mandatory.

- Table creation

  Set the option NAND_BBT_CREATE to enable the table creation if no table can be found during the scan. Usually this is done only once if a new chip is found.

- Table write support

  Set the option NAND_BBT_WRITE to enable the table write support. This allows the update of the bad block table(s) in case a block has to be marked bad due to wear. The MTD interface function block_markbad is calling the update function of the bad block table. If the write support is enabled then the table is updated on FLASH.

  Note: Write support should only be enabled for mirrored tables with version control.

- Table version control

  Set the option NAND_BBT_VERSION to enable the table version control. It's highly recommended to enable this for mirrored tables with write support. It makes sure that the risk of losing the bad block table information is reduced to the loss of the information about the one worn out block which should be marked bad. The version is stored in 4 consecutive bytes in the spare area of the device. The position of the version number is defined by the member veroffs in the bad block table descriptor.

- Save block contents on write

  In case that the block which holds the bad block table does contain other useful information, set the option NAND_BBT_SAVECONTENT. When the bad block table is written then the whole block is read the bad block table is updated and the block is erased and everything is written back. If this option is not set only the bad block table is written and everything else in the block is ignored and erased.

- Number of reserved blocks

  For automatic placement some blocks must be reserved for bad block table storage. The number of reserved blocks is defined in the maxblocks member of the babd block table description structure. Reserving 4 blocks for mirrored tables should be a reasonable number. This also limits the number of blocks which are scanned for the bad block table ident pattern.

5.4. Spare area (auto)placement

The nand driver implements different possibilities for placement of filesystem data in the spare area,

- Placement defined by fs driver
- Automatic placement

The default placement function is automatic placement. The nand driver has built in default placement schemes for the various chiptypes. If due to hardware ECC functionality the default placement does not fit then the board driver can provide a own placement scheme.

File system drivers can provide a own placement scheme which is used instead of the default placement scheme.

Placement schemes are defined by a nand_oobinfo structure

```
struct nand_oobinfo {
 int useecc;
 int eccbytes;
 int eccpos[24];
 int oobfree[8][2];
};
```

- useecc

  The useecc member controls the ecc and placement function. The header file include/mtd/mtd-abi.h contains constants to select ecc and placement. MTD_NANDECC_OFF switches off the ecc complete. This is not recommended and available for testing and diagnosis only. MTD_NANDECC_PLACE selects caller defined placement, MTD_NANDECC_AUTOPLACE selects automatic placement.
- eccbytes

  The eccbytes member defines the number of ecc bytes per page.
- eccpos

  The eccpos array holds the byte offsets in the spare area where the ecc codes are placed.
- oobfree

The oobfree array defines the areas in the spare area which can be used for automatic placement. The information is given in the format {offset, size}. offset defines the start of the usable area, size the length in bytes. More than one area can be defined. The list is terminated by an {0, 0} entry.

5.4.1. Placement defined by fs driver

The calling function provides a pointer to a nand_oobinfo structure which defines the ecc placement. For writes the caller must provide a spare area buffer along with the data buffer. The spare area buffer size is (number of pages) * (size of spare area). For reads the buffer size is (number of pages) * ((size of spare area) + (number of ecc steps per page) * sizeof (int)). The driver stores the result of the ecc check for each tuple in the spare buffer. The storage sequence is

<spare data page 0><ecc result 0>...<ecc result n>

...

<spare data page n><ecc result 0>...<ecc result n>

This is a legacy mode used by YAFFS1.

If the spare area buffer is NULL then only the ECC placement is done according to the given scheme in the nand_oobinfo structure.

5.4.2. Automatic placement

Automatic placement uses the built in defaults to place the ecc bytes in the spare area. If filesystem data have to be stored / read into the spare area then the calling function must provide a buffer. The buffer size per page is determined by the oobfree array in the nand_oobinfo structure.

If the spare area buffer is NULL then only the ECC placement is done according to the default builtin scheme.

5.4.3. User space placement selection

All non ecc functions like mtd->read and mtd->write use an internal structure, which can be set by an ioctl. This structure is preset to the autoplacement default.

```
ioctl (fd, MEMSETOOBSEL, oobsel);
```

oobsel is a pointer to a user supplied structure of type nand_oobconfig. The contents of this structure must match the criteria of the filesystem, which will be used. See an example in utils/nandwrite.c.

5.5. Spare area autoplacement default schemes

5.5.1. 256 byte pagesize

Offset	Content	Comment
0x00	ECC byte 0	Error correction code byte 0
0x01	ECC byte 1	Error correction code byte 1
0x02	ECC byte 2	Error correction code byte 2
0x03	Autoplace 0	
0x04	Autoplace 1	
0x05	Bad block marker	If any bit in this byte is zero, then this block is bad. This applies only to the first page in a block. In the remaining pages this byte is reserved
0x06	Autoplace 2	
0x07	Autoplace 3	

5.5.2. 512 byte pagesize

Offset	Content	Comment
0x00	ECC byte 0	Error correction code byte 0 of the lower 256 Byte data in this page

0x01	ECC byte 1	Error correction code byte 1 of the lower 256 Bytes of data in this page
0x02	ECC byte 2	Error correction code byte 2 of the lower 256 Bytes of data in this page
0x03	ECC byte 3	Error correction code byte 0 of the upper 256 Bytes of data in this page
0x04	reserved	reserved
0x05	Bad block marker	If any bit in this byte is zero, then this block is bad. This applies only to the first page in a block. In the remaining pages this byte is reserved
0x06	ECC byte 4	Error correction code byte 1 of the upper 256 Bytes of data in this page
0x07	ECC byte 5	Error correction code byte 2 of the upper 256 Bytes of data in this page
0x08 - 0x0F	Autoplace 0 - 7	

5.5.3. 2048 byte pagesize

Offset	Content	Comment
0x00	Bad block marker	If any bit in this byte is zero, then this block is bad. This applies only to the first page in a block. In the remaining pages this byte is reserved
0x01	Reserved	Reserved
0x02-0x27	Autoplace 0 - 37	
0x28	ECC byte 0	Error correction code byte 0 of the first 256 Byte data in this page

0x29	ECC byte 1	Error correction code byte 1 of the first 256 Bytes of data in this page
0x2A	ECC byte 2	Error correction code byte 2 of the first 256 Bytes data in this page
0x2B	ECC byte 3	Error correction code byte 0 of the second 256 Bytes of data in this page
0x2C	ECC byte 4	Error correction code byte 1 of the second 256 Bytes of data in this page
0x2D	ECC byte 5	Error correction code byte 2 of the second 256 Bytes of data in this page
0x2E	ECC byte 6	Error correction code byte 0 of the third 256 Bytes of data in this page
0x2F	ECC byte 7	Error correction code byte 1 of the third 256 Bytes of data in this page
0x30	ECC byte 8	Error correction code byte 2 of the third 256 Bytes of data in this page
0x31	ECC byte 9	Error correction code byte 0 of the fourth 256 Bytes of data in this page
0x32	ECC byte 10	Error correction code byte 1 of the fourth 256 Bytes of data in this page
0x33	ECC byte 11	Error correction code byte 2 of the fourth 256 Bytes of data in this page
0x34	ECC byte 12	Error correction code byte 0 of the fifth 256 Bytes of data in this page
0x35	ECC byte 13	Error correction code byte 1 of the fifth 256 Bytes of data in this page

0x36	ECC byte 14	Error correction code byte 2 of the fifth 256 Bytes of data in this page
0x37	ECC byte 15	Error correction code byte 0 of the sixt 256 Bytes of data in this page
0x38	ECC byte 16	Error correction code byte 1 of the sixt 256 Bytes of data in this page
0x39	ECC byte 17	Error correction code byte 2 of the sixt 256 Bytes of data in this page
0x3A	ECC byte 18	Error correction code byte 0 of the seventh 256 Bytes of data in this page
0x3B	ECC byte 19	Error correction code byte 1 of the seventh 256 Bytes of data in this page
0x3C	ECC byte 20	Error correction code byte 2 of the seventh 256 Bytes of data in this page
0x3D	ECC byte 21	Error correction code byte 0 of the eighth 256 Bytes of data in this page
0x3E	ECC byte 22	Error correction code byte 1 of the eighth 256 Bytes of data in this page
0x3F	ECC byte 23	Error correction code byte 2 of the eighth 256 Bytes of data in this page

Chapter 6. Filesystem support

The NAND driver provides all neccecary functions for a filesystem via the MTD interface.

Filesystems must be aware of the NAND pecularities and restrictions. One major restrictions of NAND Flash is, that you cannot write as often as you want to a page. The consecutive writes to a page, before erasing it again, are restricted to 1-3 writes, depending on the manufacturers specifications. This applies similar to the spare area.

Therefore NAND aware filesystems must either write in page size chunks or hold a writebuffer to collect smaller writes until they sum up to pagesize. Available NAND aware filesystems: JFFS2, YAFFS.

The spare area usage to store filesystem data is controlled by the spare area placement functionality which is described in one of the earlier chapters.

Chapter 7. Tools

The MTD project provides a couple of helpful tools to handle NAND Flash.

- flasherase, flasheraseall: Erase and format FLASH partitions
- nandwrite: write filesystem images to NAND FLASH
- nanddump: dump the contents of a NAND FLASH partitions

These tools are aware of the NAND restrictions. Please use those tools instead of complaining about errors which are caused by non NAND aware access methods.

Chapter 8. Constants

This chapter describes the constants which might be relevant for a driver developer.

8.1. Chip option constants

8.1.1. Constants for chip id table

These constants are defined in nand.h. They are ored together to describe the chip functionality.

```
/* Chip can not auto increment pages */
#define NAND_NO_AUTOINCR 0x00000001
/* Buswitdh is 16 bit */
#define NAND_BUSWIDTH_16 0x00000002
/* Device supports partial programming without padding */
#define NAND_NO_PADDING  0x00000004
/* Chip has cache program function */
#define NAND_CACHEPRG  0x00000008
/* Chip has copy back function */
#define NAND_COPYBACK  0x00000010
/* AND Chip which has 4 banks and a confusing page / block
 * assignment. See Renesas datasheet for further information */
#define NAND_IS_AND  0x00000020
/* Chip has a array of 4 pages which can be read without
 * additional ready /busy waits */
#define NAND_4PAGE_ARRAY 0x00000040
```

8.1.2. Constants for runtime options

These constants are defined in nand.h. They are ored together to describe the functionality.

```
/* Use a flash based bad block table. This option is parsed by the
 * default bad block table function (nand_default_bbt). */
#define NAND_USE_FLASH_BBT 0x00010000
/* The hw ecc generator provides a syndrome instead a ecc value on read
 * This can only work if we have the ecc bytes directly behind the
 * data bytes. Applies for DOC and AG-AND Renesas HW Reed Solomon generato
```

```
#define NAND_HWECC_SYNDROME 0x00020000
```

8.2. ECC selection constants

Use these constants to select the ECC algorithm.

```
/* No ECC. Usage is not recommended ! */
#define NAND_ECC_NONE  0
/* Software ECC 3 byte ECC per 256 Byte data */
#define NAND_ECC_SOFT  1
/* Hardware ECC 3 byte ECC per 256 Byte data */
#define NAND_ECC_HW3_256 2
/* Hardware ECC 3 byte ECC per 512 Byte data */
#define NAND_ECC_HW3_512 3
/* Hardware ECC 6 byte ECC per 512 Byte data */
#define NAND_ECC_HW6_512 4
/* Hardware ECC 6 byte ECC per 512 Byte data */
#define NAND_ECC_HW8_512 6
```

8.3. Hardware control related constants

These constants describe the requested hardware access function when the boardspecific hardware control function is called

```
/* Select the chip by setting nCE to low */
#define NAND_CTL_SETNCE  1
/* Deselect the chip by setting nCE to high */
#define NAND_CTL_CLRNCE  2
/* Select the command latch by setting CLE to high */
#define NAND_CTL_SETCLE  3
/* Deselect the command latch by setting CLE to low */
#define NAND_CTL_CLRCLE  4
/* Select the address latch by setting ALE to high */
#define NAND_CTL_SETALE  5
/* Deselect the address latch by setting ALE to low */
#define NAND_CTL_CLRALE  6
/* Set write protection by setting WP to high. Not used! */
```

```
#define NAND_CTL_SETWP  7
/* Clear write protection by setting WP to low. Not used! */
#define NAND_CTL_CLRWP  8
```

8.4. Bad block table related constants

These constants describe the options used for bad block table descriptors.

```
/* Options for the bad block table descriptors */

/* The number of bits used per block in the bbt on the device */
#define NAND_BBT_NRBITS_MSK 0x0000000F
#define NAND_BBT_1BIT  0x00000001
#define NAND_BBT_2BIT  0x00000002
#define NAND_BBT_4BIT  0x00000004
#define NAND_BBT_8BIT  0x00000008
/* The bad block table is in the last good block of the device */
#define NAND_BBT_LASTBLOCK 0x00000010
/* The bbt is at the given page, else we must scan for the bbt */
#define NAND_BBT_ABSPAGE 0x00000020
/* The bbt is at the given page, else we must scan for the bbt */
#define NAND_BBT_SEARCH  0x00000040
/* bbt is stored per chip on multichip devices */
#define NAND_BBT_PERCHIP 0x00000080
/* bbt has a version counter at offset veroffs */
#define NAND_BBT_VERSION 0x00000100
/* Create a bbt if none axists */
#define NAND_BBT_CREATE  0x00000200
/* Search good / bad pattern through all pages of a block */
#define NAND_BBT_SCANALLPAGES 0x00000400
/* Scan block empty during good / bad block scan */
#define NAND_BBT_SCANEMPTY 0x00000800
/* Write bbt if neccecary */
#define NAND_BBT_WRITE  0x00001000
/* Read and write back block contents when writing bbt */
#define NAND_BBT_SAVECONTENT 0x00002000
```

Chapter 9. Structures

This chapter contains the autogenerated documentation of the structures which are used in the NAND driver and might be relevant for a driver developer. Each struct member has a short description which is marked with an [XXX] identifier. See the chapter "Documentation hints" for an explanation.

struct nand_hw_control

LINUX

Kernel Hackers ManualOctober 2026

Name

`struct nand_hw_control` — Control structure for hardware controller (e.g ECC generator) shared among independent devices

Synopsis

```
struct nand_hw_control {
  spinlock_t lock;
  struct nand_chip * active;
  wait_queue_head_t wq;
};
```

Members

lock

protection lock

active

the mtd device which holds the controller currently

wq

wait queue to sleep on if a NAND operation is in progress used instead of the per chip wait queue when a hw controller is available.

struct nand_ecc_ctrl

LINUX

Kernel Hackers ManualOctober 2026

Name

`struct nand_ecc_ctrl` — Control structure for ecc

Synopsis

```
struct nand_ecc_ctrl {
  nand_ecc_modes_t mode;
  int steps;
  int size;
  int bytes;
  int total;
  int prepad;
  int postpad;
  struct nand_ecclayout * layout;
  void * priv;
  void (* hwctl) (struct mtd_info *mtd, int mode);
  int (* calculate) (struct mtd_info *mtd, const uint8_t *dat,uint8_t *ec
  int (* correct) (struct mtd_info *mtd, uint8_t *dat, uint8_t *read_ecc,
  int (* read_page_raw) (struct mtd_info *mtd, struct nand_chip *chip,uin
  void (* write_page_raw) (struct mtd_info *mtd, struct nand_chip *chip,c
  int (* read_page) (struct mtd_info *mtd, struct nand_chip *chip,uint8_t
  int (* read_subpage) (struct mtd_info *mtd, struct nand_chip *chip,uint
  void (* write_page) (struct mtd_info *mtd, struct nand_chip *chip,const
  int (* read_oob) (struct mtd_info *mtd, struct nand_chip *chip, int pag
  int (* write_oob) (struct mtd_info *mtd, struct nand_chip *chip,int pag
};
```

Members

mode

ecc mode

steps

number of ecc steps per page

size

data bytes per ecc step

bytes

ecc bytes per step

total

total number of ecc bytes per page

prepad

padding information for syndrome based ecc generators

postpad

padding information for syndrome based ecc generators

layout

ECC layout control struct pointer

priv

pointer to private ecc control data

hwctl

function to control hardware ecc generator. Must only be provided if an hardware ECC is available

calculate

function for ecc calculation or readback from ecc hardware

correct

function for ecc correction, matching to ecc generator (sw/hw)

read_page_raw

function to read a raw page without ECC

write_page_raw

function to write a raw page without ECC

read_page

function to read a page according to the ecc generator requirements.

read_subpage

function to read parts of the page covered by ECC.

write_page

function to write a page according to the ecc generator requirements.

read_oob

function to read chip OOB data

write_oob

function to write chip OOB data

struct nand_buffers

LINUX

Kernel Hackers ManualOctober 2026

Name

`struct nand_buffers` — buffer structure for read/write

Synopsis

```
struct nand_buffers {
  uint8_t ecccalc[NAND_MAX_OOBSIZE];
  uint8_t ecccode[NAND_MAX_OOBSIZE];
  uint8_t databuf[NAND_MAX_PAGESIZE + NAND_MAX_OOBSIZE];
};
```

Members

ecccalc[NAND_MAX_OOBSIZE]

buffer for calculated ecc

ecccode[NAND_MAX_OOBSIZE]

buffer for ecc read from flash

databuf[NAND_MAX_PAGESIZE + NAND_MAX_OOBSIZE]

buffer for data - dynamically sized

Description

Do not change the order of buffers. databuf and oobrbuf must be in consecutive order.

struct nand_chip

LINUX

Kernel Hackers ManualOctober 2026

Name

`struct nand_chip` — NAND Private Flash Chip Data

Synopsis

```
struct nand_chip {
  void __iomem * IO_ADDR_R;
  void __iomem * IO_ADDR_W;
  uint8_t (* read_byte) (struct mtd_info *mtd);
  u16 (* read_word) (struct mtd_info *mtd);
  void (* write_buf) (struct mtd_info *mtd, const uint8_t *buf, int len);
  void (* read_buf) (struct mtd_info *mtd, uint8_t *buf, int len);
  int (* verify_buf) (struct mtd_info *mtd, const uint8_t *buf, int len);
  void (* select_chip) (struct mtd_info *mtd, int chip);
```

```
    int (* block_bad) (struct mtd_info *mtd, loff_t ofs, int getchip);
    int (* block_markbad) (struct mtd_info *mtd, loff_t ofs);
    void (* cmd_ctrl) (struct mtd_info *mtd, int dat, unsigned int ctrl);
    int (* init_size) (struct mtd_info *mtd, struct nand_chip *this,u8 *id_c
    int (* dev_ready) (struct mtd_info *mtd);
    void (* cmdfunc) (struct mtd_info *mtd, unsigned command, int column,int
    int(* waitfunc) (struct mtd_info *mtd, struct nand_chip *this);
    void (* erase_cmd) (struct mtd_info *mtd, int page);
    int (* scan_bbt) (struct mtd_info *mtd);
    int (* errstat) (struct mtd_info *mtd, struct nand_chip *this, int state
    int (* write_page) (struct mtd_info *mtd, struct nand_chip *chip,const u
    int chip_delay;
    unsigned int options;
    int page_shift;
    int phys_erase_shift;
    int bbt_erase_shift;
    int chip_shift;
    int numchips;
    uint64_t chipsize;
    int pagemask;
    int pagebuf;
    int subpagesize;
    uint8_t cellinfo;
    int badblockpos;
    int badblockbits;
    int onfi_version;
    struct nand_onfi_params onfi_params;
    flstate_t state;
    uint8_t * oob_poi;
    struct nand_hw_control * controller;
    struct nand_ecclayout * ecclayout;
    struct nand_ecc_ctrl ecc;
    struct nand_buffers * buffers;
    struct nand_hw_control hwcontrol;
    struct mtd_oob_ops ops;
    uint8_t * bbt;
    struct nand_bbt_descr * bbt_td;
    struct nand_bbt_descr * bbt_md;
    struct nand_bbt_descr * badblock_pattern;
    void * priv;
};
```

Members

IO_ADDR_R

[BOARDSPECIFIC] address to read the 8 I/O lines of the flash device

IO_ADDR_W

[BOARDSPECIFIC] address to write the 8 I/O lines of the flash device.

read_byte

[REPLACEABLE] read one byte from the chip

read_word

[REPLACEABLE] read one word from the chip

write_buf

[REPLACEABLE] write data from the buffer to the chip

read_buf

[REPLACEABLE] read data from the chip into the buffer

verify_buf

[REPLACEABLE] verify buffer contents against the chip data.

select_chip

[REPLACEABLE] select chip nr

block_bad

[REPLACEABLE] check, if the block is bad

block_markbad

[REPLACEABLE] mark the block bad

cmd_ctrl

[BOARDSPECIFIC] hardwarespecific function for controlling ALE/CLE/nCE. Also used to write command and address

init_size

[BOARDSPECIFIC] hardwarespecific function for setting mtd->oobsize, mtd->writesize and so on. `id_data` contains the 8 bytes values of NAND_CMD_READID. Return with the bus width.

dev_ready

[BOARDSPECIFIC] hardwarespecific function for accesing device ready/busy line. If set to NULL no access to ready/busy is available and the ready/busy information is read from the chip status register.

cmdfunc

[REPLACEABLE] hardwarespecific function for writing commands to the chip.

waitfunc

[REPLACEABLE] hardwarespecific function for wait on ready.

erase_cmd

[INTERN] erase command write function, selectable due to AND support.

scan_bbt

[REPLACEABLE] function to scan bad block table

errstat

[OPTIONAL] hardware specific function to perform additional error status checks (determine if errors are correctable).

write_page

[REPLACEABLE] High-level page write function

chip_delay

[BOARDSPECIFIC] chip dependent delay for transferring data from array to read regs (tR).

options

[BOARDSPECIFIC] various chip options. They can partly be set to inform nand_scan about special functionality. See the defines for further explanation.

page_shift

[INTERN] number of address bits in a page (column address bits).

phys_erase_shift

[INTERN] number of address bits in a physical eraseblock

bbt_erase_shift

[INTERN] number of address bits in a bbt entry

chip_shift

[INTERN] number of address bits in one chip

numchips

[INTERN] number of physical chips

chipsize

[INTERN] the size of one chip for multichip arrays

pagemask

[INTERN] page number mask = number of (pages / chip) - 1

pagebuf

[INTERN] holds the pagenumber which is currently in data_buf.

subpagesize

[INTERN] holds the subpagesize

cellinfo

[INTERN] MLC/multichip data from chip ident

badblockpos

[INTERN] position of the bad block marker in the oob area.

badblockbits

[INTERN] number of bits to left-shift the bad block number

onfi_version

[INTERN] holds the chip ONFI version (BCD encoded), non 0 if ONFI supported.

onfi_params

[INTERN] holds the ONFI page parameter when ONFI is supported, 0 otherwise.

state

[INTERN] the current state of the NAND device

oob_poi

poison value buffer

controller

[REPLACEABLE] a pointer to a hardware controller structure which is shared among multiple independend devices.

ecclayout

[REPLACEABLE] the default ecc placement scheme

ecc

[BOARDSPECIFIC] ecc control ctructure

buffers

buffer structure for read/write

hwcontrol

platform-specific hardware control structure

ops

oob operation operands

bbt

[INTERN] bad block table pointer

bbt_td

[REPLACEABLE] bad block table descriptor for flash lookup.

bbt_md

[REPLACEABLE] bad block table mirror descriptor

badblock_pattern

[REPLACEABLE] bad block scan pattern used for initial bad block scan.

priv

[OPTIONAL] pointer to private chip date

struct nand_flash_dev

LINUX

Name

`struct nand_flash_dev` — NAND Flash Device ID Structure

Synopsis

```
struct nand_flash_dev {
  char * name;
  int id;
  unsigned long pagesize;
  unsigned long chipsize;
  unsigned long erasesize;
  unsigned long options;
};
```

Members

name

Identify the device type

id

device ID code

pagesize

Pagesize in bytes. Either 256 or 512 or 0 If the pagesize is 0, then the real pagesize and the eraseize are determined from the extended id bytes in the chip

chipsize

Total chipsize in Mega Bytes

erasesize

Size of an erase block in the flash device.

options

Bitfield to store chip relevant options

struct nand_manufacturers

LINUX

Kernel Hackers ManualOctober 2026

Name

`struct nand_manufacturers` — NAND Flash Manufacturer ID Structure

Synopsis

```
struct nand_manufacturers {
  int id;
  char * name;
};
```

Members

id

manufacturer ID code of device.

name

Manufacturer name

struct platform_nand_chip

LINUX

Kernel Hackers ManualOctober 2026

Name

`struct platform_nand_chip` — chip level device structure

Synopsis

```
struct platform_nand_chip {
  int nr_chips;
  int chip_offset;
  int nr_partitions;
  struct mtd_partition * partitions;
  struct nand_ecclayout * ecclayout;
  int chip_delay;
  unsigned int options;
  const char ** part_probe_types;
  void (* set_parts) (uint64_t size, struct platform_nand_chip *chip);
  void * priv;
};
```

Members

nr_chips

max. number of chips to scan for

chip_offset

chip number offset

nr_partitions

number of partitions pointed to by partitions (or zero)

partitions

mtd partition list

ecclayout

ecc layout info structure

chip_delay

R/B delay value in us

options

Option flags, e.g. 16bit buswidth

part_probe_types

NULL-terminated array of probe types

set_parts

platform specific function to set partitions

priv

hardware controller specific settings

struct platform_nand_ctrl

LINUX

Kernel Hackers ManualOctober 2026

Name

`struct platform_nand_ctrl` — controller level device structure

Synopsis

```
struct platform_nand_ctrl {
  int (* probe) (struct platform_device *pdev);
  void (* remove) (struct platform_device *pdev);
  void (* hwcontrol) (struct mtd_info *mtd, int cmd);
  int (* dev_ready) (struct mtd_info *mtd);
  void (* select_chip) (struct mtd_info *mtd, int chip);
  void (* cmd_ctrl) (struct mtd_info *mtd, int dat, unsigned int ctrl);
  void (* write_buf) (struct mtd_info *mtd, const uint8_t *buf, int len);
  void (* read_buf) (struct mtd_info *mtd, uint8_t *buf, int len);
  void * priv;
};
```

Members

probe

platform specific function to probe/setup hardware

remove

platform specific function to remove/teardown hardware

hwcontrol

platform specific hardware control structure

dev_ready

platform specific function to read ready/busy pin

select_chip

platform specific chip select function

cmd_ctrl

platform specific function for controlling ALE/CLE/nCE. Also used to write command and address

write_buf

platform specific function for write buffer

read_buf

platform specific function for read buffer

priv

private data to transport driver specific settings

Description

All fields are optional and depend on the hardware driver requirements

struct platform_nand_data

LINUX

Name

`struct platform_nand_data` — container structure for platform-specific data

Synopsis

```
struct platform_nand_data {
  struct platform_nand_chip chip;
  struct platform_nand_ctrl ctrl;
};
```

Members

chip

chip level chip structure

ctrl

controller level device structure

Chapter 10. Public Functions Provided

This chapter contains the autogenerated documentation of the NAND kernel API functions which are exported. Each function has a short description which is marked with an [XXX] identifier. See the chapter "Documentation hints" for an explanation.

nand_unlock

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_unlock` — [REPLACEABLE] unlocks specified locked blocks

Synopsis

```
int nand_unlock (struct mtd_info * mtd, loff_t ofs, uint64_t
len);
```

Arguments

mtd

mtd info

ofs

offset to start unlock from

len

length to unlock

Description

return - unlock status

nand_lock

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_lock` — [REPLACEABLE] locks all blocks present in the device

Synopsis

```
int nand_lock (struct mtd_info * mtd, loff_t ofs, uint64_t
len);
```

Arguments

mtd

mtd info

ofs

offset to start unlock from

len

length to unlock

Description

return - lock status

This feature is not supported in many NAND parts. 'Micron' NAND parts do have this feature, but it allows only to lock all blocks, not for specified range for block.

Implementing 'lock' feature by making use of 'unlock', for now.

nand_scan_ident

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_scan_ident` — [NAND Interface] Scan for the NAND device

Synopsis

```
int nand_scan_ident (struct mtd_info * mtd, int maxchips,
struct nand_flash_dev * table);
```

Arguments

mtd

MTD device structure

maxchips

Number of chips to scan for

table

Alternative NAND ID table

Description

This is the first phase of the normal `nand_scan` function. It reads the flash ID and sets up MTD fields accordingly.

The mtd->owner field must be set to the module of the caller.

nand_scan_tail

Name

`nand_scan_tail` — [NAND Interface] Scan for the NAND device

Synopsis

```
int nand_scan_tail (struct mtd_info * mtd);
```

Arguments

mtd

MTD device structure

Description

This is the second phase of the normal `nand_scan` function. It fills out all the uninitialized function pointers with the defaults and scans for a bad block table if appropriate.

nand_scan

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_scan` — [NAND Interface] Scan for the NAND device

Synopsis

```
int nand_scan (struct mtd_info * mtd, int maxchips);
```

Arguments

mtd

MTD device structure

maxchips

Number of chips to scan for

Description

This fills out all the uninitialized function pointers with the defaults. The flash ID is read and the mtd/chip structures are filled with the appropriate values. The mtd->owner field must be set to the module of the caller

nand_release

LINUX

Name

`nand_release` — [NAND Interface] Free resources held by the NAND device

Synopsis

```
void nand_release (struct mtd_info * mtd);
```

Arguments

`mtd`

MTD device structure

nand_scan_bbt

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_scan_bbt` — [NAND Interface] scan, find, read and maybe create bad block table(s)

Synopsis

```
int nand_scan_bbt (struct mtd_info * mtd, struct
nand_bbt_descr * bd);
```

Arguments

mtd

MTD device structure

bd

descriptor for the good/bad block search pattern

Description

The function checks, if a bad block table(s) is/are already available. If not it scans the device for manufacturer marked good / bad blocks and writes the bad block table(s) to the selected place.

The bad block table memory is allocated here. It must be freed by calling the nand_free_bbt function.

nand_default_bbt

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_default_bbt` — [NAND Interface] Select a default bad block table for the device

Synopsis

```
int nand_default_bbt (struct mtd_info * mtd);
```

Arguments

mtd

MTD device structure

Description

This function selects the default bad block table support for the device and calls the nand_scan_bbt function

__nand_calculate_ecc

LINUX

Kernel Hackers ManualOctober 2026

Name

`__nand_calculate_ecc` — [NAND Interface] Calculate 3-byte ECC for 256/512-byte block

Synopsis

```
void __nand_calculate_ecc (const unsigned char * buf, unsigned
int eccsize, unsigned char * code);
```

Arguments

buf

input buffer with raw data

eccsize

data bytes per ecc step (256 or 512)

code

output buffer with ECC

nand_calculate_ecc

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_calculate_ecc` — [NAND Interface] Calculate 3-byte ECC for 256/512-byte block

Synopsis

```
int nand_calculate_ecc (struct mtd_info * mtd, const unsigned
char * buf, unsigned char * code);
```

Arguments

mtd

MTD block structure

buf

input buffer with raw data

code

output buffer with ECC

__nand_correct_data

LINUX

Kernel Hackers ManualOctober 2026

Name

`__nand_correct_data` — [NAND Interface] Detect and correct bit error(s)

Synopsis

```
int __nand_correct_data (unsigned char * buf, unsigned char *
read_ecc, unsigned char * calc_ecc, unsigned int eccsize);
```

Arguments

buf

raw data read from the chip

read_ecc

ECC from the chip

calc_ecc

the ECC calculated from raw data

eccsize

data bytes per ecc step (256 or 512)

Description

Detect and correct a 1 bit error for eccsize byte block

nand_correct_data

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_correct_data` — [NAND Interface] Detect and correct bit error(s)

Synopsis

```
int nand_correct_data (struct mtd_info * mtd, unsigned char *
buf, unsigned char * read_ecc, unsigned char * calc_ecc);
```

Arguments

mtd

MTD block structure

buf

raw data read from the chip

read_ecc

ECC from the chip

calc_ecc

the ECC calculated from raw data

Description

Detect and correct a 1 bit error for 256/512 byte block

Chapter 11. Internal Functions Provided

This chapter contains the autogenerated documentation of the NAND driver internal functions. Each function has a short description which is marked with an [XXX] identifier. See the chapter "Documentation hints" for an explanation. The functions marked with [DEFAULT] might be relevant for a board driver developer.

nand_release_device

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_release_device` — [GENERIC] release chip

Synopsis

```
void nand_release_device (struct mtd_info * mtd);
```

Arguments

`mtd`

MTD device structure

Description

Deselect, release chip lock and wake up anyone waiting on the device

nand_read_byte

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_read_byte` — [DEFAULT] read one byte from the chip

Synopsis

```
uint8_t nand_read_byte (struct mtd_info * mtd);
```

Arguments

mtd

MTD device structure

Description

Default read function for 8bit buswith

nand_read_byte16

LINUX

Name

`nand_read_byte16` — [DEFAULT] read one byte endianess aware from the chip

Synopsis

```
uint8_t nand_read_byte16 (struct mtd_info * mtd);
```

Arguments

`mtd`

MTD device structure

Description

Default read function for 16bit buswith with endianess conversion

nand_read_word

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_read_word` — [DEFAULT] read one word from the chip

Synopsis

```
u16 nand_read_word (struct mtd_info * mtd);
```

Arguments

mtd

MTD device structure

Description

Default read function for 16bit buswith without endianess conversion

nand_select_chip

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_select_chip` — [DEFAULT] control CE line

Synopsis

```
void nand_select_chip (struct mtd_info * mtd, int chipnr);
```

Arguments

mtd

MTD device structure

chipnr

chipnumber to select, -1 for deselect

Description

Default select function for 1 chip devices.

nand_write_buf

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_write_buf` — [DEFAULT] write buffer to chip

Synopsis

```
void nand_write_buf (struct mtd_info * mtd, const uint8_t *
buf, int len);
```

Arguments

mtd

MTD device structure

buf

data buffer

len

number of bytes to write

Description

Default write function for 8bit buswith

nand_read_buf

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_read_buf` — [DEFAULT] read chip data into buffer

Synopsis

```
void nand_read_buf (struct mtd_info * mtd, uint8_t * buf, int
len);
```

Arguments

mtd

MTD device structure

buf

buffer to store date

len

number of bytes to read

Description

Default read function for 8bit buswith

nand_verify_buf

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_verify_buf` — [DEFAULT] Verify chip data against buffer

Synopsis

```
int nand_verify_buf (struct mtd_info * mtd, const uint8_t *
buf, int len);
```

Arguments

mtd

MTD device structure

buf

buffer containing the data to compare

len

number of bytes to compare

Description

Default verify function for 8bit buswith

nand_write_buf16

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_write_buf16` — [DEFAULT] write buffer to chip

Synopsis

```
void nand_write_buf16 (struct mtd_info * mtd, const uint8_t *
buf, int len);
```

Arguments

mtd

MTD device structure

buf

data buffer

len

number of bytes to write

Description

Default write function for 16bit buswith

nand_read_buf16

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_read_buf16` — [DEFAULT] read chip data into buffer

Synopsis

```
void nand_read_buf16 (struct mtd_info * mtd, uint8_t * buf,
int len);
```

Arguments

mtd

MTD device structure

buf

buffer to store date

len

number of bytes to read

Description

Default read function for 16bit buswith

nand_verify_buf16

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_verify_buf16` — [DEFAULT] Verify chip data against buffer

Synopsis

```
int nand_verify_buf16 (struct mtd_info * mtd, const uint8_t *
buf, int len);
```

Arguments

mtd

MTD device structure

buf

buffer containing the data to compare

len

number of bytes to compare

Description

Default verify function for 16bit buswith

nand_block_bad

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_block_bad` — [DEFAULT] Read bad block marker from the chip

Synopsis

```
int nand_block_bad (struct mtd_info * mtd, loff_t ofs, int
getchip);
```

Arguments

mtd

MTD device structure

ofs

offset from device start

getchip

0, if the chip is already selected

Description

Check, if the block is bad.

nand_default_block_markbad

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_default_block_markbad` — [DEFAULT] mark a block bad

Synopsis

```
int nand_default_block_markbad (struct mtd_info * mtd, loff_t
ofs);
```

Arguments

mtd

MTD device structure

ofs

offset from device start

Description

This is the default implementation, which can be overridden by a hardware specific driver.

nand_check_wp

LINUX

Name

`nand_check_wp` — [GENERIC] check if the chip is write protected

Synopsis

```
int nand_check_wp (struct mtd_info * mtd);
```

Arguments

mtd

MTD device structure Check, if the device is write protected

Description

The function expects, that the device is already selected

nand_block_checkbad

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_block_checkbad` — [GENERIC] Check if a block is marked bad

Synopsis

```
int nand_block_checkbad (struct mtd_info * mtd, loff_t ofs,
int getchip, int allowbbt);
```

Arguments

mtd

MTD device structure

ofs

offset from device start

getchip

0, if the chip is already selected

allowbbt

1, if its allowed to access the bbt area

Description

Check, if the block is bad. Either by reading the bad block table or calling of the scan function.

panic_nand_wait_ready

LINUX

Kernel Hackers ManualOctober 2026

Name

`panic_nand_wait_ready` — [GENERIC] Wait for the ready pin after

commands.

Synopsis

```
void panic_nand_wait_ready (struct mtd_info * mtd, unsigned long timeo);
```

Arguments

mtd

MTD device structure

timeo

Timeout

Description

Helper function for nand_wait_ready used when needing to wait in interrupt context.

nand_command

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_command` — [DEFAULT] Send command to NAND device

Synopsis

```
void nand_command (struct mtd_info * mtd, unsigned int
command, int column, int page_addr);
```

Arguments

mtd

MTD device structure

command

the command to be sent

column

the column address for this command, -1 if none

page_addr

the page address for this command, -1 if none

Description

Send command to NAND device. This function is used for small page devices (256/512 Bytes per page)

nand_command_lp

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_command_lp` — [DEFAULT] Send command to NAND large page device

Synopsis

```
void nand_command_lp (struct mtd_info * mtd, unsigned int
command, int column, int page_addr);
```

Arguments

mtd

MTD device structure

command

the command to be sent

column

the column address for this command, -1 if none

page_addr

the page address for this command, -1 if none

Description

Send command to NAND device. This is the version for the new large page devices We dont have the separate regions as we have in the small page devices. We must emulate NAND_CMD_READOOB to keep the code compatible.

panic_nand_get_device

LINUX

Name

`panic_nand_get_device` — [GENERIC] Get chip for selected access

Synopsis

```
void panic_nand_get_device (struct nand_chip * chip, struct
mtd_info * mtd, int new_state);
```

Arguments

`chip`

the nand chip descriptor

`mtd`

MTD device structure

`new_state`

the state which is requested

Description

Used when in panic, no locks are taken.

nand_get_device

LINUX

Name

`nand_get_device` — [GENERIC] Get chip for selected access

Synopsis

```
int nand_get_device (struct nand_chip * chip, struct mtd_info
* mtd, int new_state);
```

Arguments

chip

the nand chip descriptor

mtd

MTD device structure

new_state

the state which is requested

Description

Get the device and lock it for exclusive access

panic_nand_wait

LINUX

Name

`panic_nand_wait` — [GENERIC] wait until the command is done

Synopsis

```
void panic_nand_wait (struct mtd_info * mtd, struct nand_chip
* chip, unsigned long timeo);
```

Arguments

`mtd`

MTD device structure

`chip`

NAND chip structure

`timeo`

Timeout

Description

Wait for command done. This is a helper function for nand_wait used when we are in interrupt context. May happen when in panic and trying to write an oops through mtdoops.

nand_wait

LINUX

Name

`nand_wait` — [DEFAULT] wait until the command is done

Synopsis

```
int nand_wait (struct mtd_info * mtd, struct nand_chip *
chip);
```

Arguments

mtd

MTD device structure

chip

NAND chip structure

Description

Wait for command done. This applies to erase and program only Erase can take up to 400ms and program up to 20ms according to general NAND and SmartMedia specs

__nand_unlock

LINUX

Name

`__nand_unlock` — [REPLACEABLE] unlocks specified locked blocks

Synopsis

```
int __nand_unlock (struct mtd_info * mtd, loff_t ofs, uint64_t
len, int invert);
```

Arguments

`mtd`

mtd info

`ofs`

offset to start unlock from

`len`

length to unlock

`invert`

when = 0, unlock the range of blocks within the lower and upper boundary address when = 1, unlock the range of blocks outside the boundaries of the lower and upper boundary address

Description

return - unlock status

nand_read_page_raw

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_read_page_raw` — [Intern] read raw page data without ecc

Synopsis

```
int nand_read_page_raw (struct mtd_info * mtd, struct
nand_chip * chip, uint8_t * buf, int page);
```

Arguments

mtd

mtd info structure

chip

nand chip info structure

buf

buffer to store read data

page

page number to read

Description

Not for syndrome calculating ecc controllers, which use a special oob layout

nand_read_page_raw_syndrome

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_read_page_raw_syndrome` — [Intern] read raw page data without ecc

Synopsis

```
int nand_read_page_raw_syndrome (struct mtd_info * mtd, struct
nand_chip * chip, uint8_t * buf, int page);
```

Arguments

mtd

mtd info structure

chip

nand chip info structure

buf

buffer to store read data

page

page number to read

Description

We need a special oob layout and handling even when OOB isn't used.

nand_read_page_swecc

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_read_page_swecc` — [REPLACABLE] software ecc based page read function

Synopsis

```
int nand_read_page_swecc (struct mtd_info * mtd, struct
nand_chip * chip, uint8_t * buf, int page);
```

Arguments

mtd

mtd info structure

chip

nand chip info structure

buf

buffer to store read data

page

page number to read

nand_read_subpage

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_read_subpage` — [REPLACABLE] software ecc based sub-page read function

Synopsis

```
int nand_read_subpage (struct mtd_info * mtd, struct nand_chip
* chip, uint32_t data_offs, uint32_t readlen, uint8_t *
bufpoi);
```

Arguments

mtd

mtd info structure

chip

nand chip info structure

data_offs

offset of requested data within the page

readlen

data length

bufpoi

buffer to store read data

nand_read_page_hwecc

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_read_page_hwecc` — [REPLACABLE] hardware ecc based page read function

Synopsis

```
int nand_read_page_hwecc (struct mtd_info * mtd, struct
nand_chip * chip, uint8_t * buf, int page);
```

Arguments

mtd

mtd info structure

chip

nand chip info structure

buf

buffer to store read data

page

page number to read

Description

Not for syndrome calculating ecc controllers which need a special oob layout

nand_read_page_hwecc_oob_first

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_read_page_hwecc_oob_first` — [REPLACABLE] hw ecc, read oob first

Synopsis

```
int nand_read_page_hwecc_oob_first (struct mtd_info * mtd,
struct nand_chip * chip, uint8_t * buf, int page);
```

Arguments

`mtd`

mtd info structure

`chip`

nand chip info structure

`buf`

buffer to store read data

`page`

page number to read

Description

Hardware ECC for large page chips, require OOB to be read first. For this ECC mode, the write_page method is re-used from ECC_HW. These methods read/write ECC from the OOB area, unlike the ECC_HW_SYNDROME support with multiple

ECC steps, follows the “infix ECC” scheme and reads/writes ECC from the data area, by overwriting the NAND manufacturer bad block markings.

nand_read_page_syndrome

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_read_page_syndrome` — [REPLACABLE] hardware ecc syndrom based page read

Synopsis

```
int nand_read_page_syndrome (struct mtd_info * mtd, struct
nand_chip * chip, uint8_t * buf, int page);
```

Arguments

mtd

mtd info structure

chip

nand chip info structure

buf

buffer to store read data

page

page number to read

Description

The hw generator calculates the error syndrome automatically. Therefor we need a special oob layout and handling.

nand_transfer_oob

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_transfer_oob` — [Internal] Transfer oob to client buffer

Synopsis

```
uint8_t * nand_transfer_oob (struct nand_chip * chip, uint8_t
* oob, struct mtd_oob_ops * ops, size_t len);
```

Arguments

chip

nand chip structure

oob

oob destination address

ops

oob ops structure

len

size of oob to transfer

nand_do_read_ops

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_do_read_ops` — [Internal] Read data with ECC

Synopsis

```
int nand_do_read_ops (struct mtd_info * mtd, loff_t from,
struct mtd_oob_ops * ops);
```

Arguments

mtd

MTD device structure

from

offset to read from

ops

oob ops structure

Description

Internal function. Called with chip held.

nand_read

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_read` — [MTD Interface] MTD compatibility function for nand_do_read_ecc

Synopsis

```
int nand_read (struct mtd_info * mtd, loff_t from, size_t len,
size_t * retlen, uint8_t * buf);
```

Arguments

`mtd`

MTD device structure

`from`

offset to read from

`len`

number of bytes to read

`retlen`

pointer to variable to store the number of read bytes

`buf`

the databuffer to put data

Description

Get hold of the chip and call nand_do_read

nand_read_oob_std

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_read_oob_std` — [REPLACABLE] the most common OOB data read function

Synopsis

```
int nand_read_oob_std (struct mtd_info * mtd, struct nand_chip
* chip, int page, int sndcmd);
```

Arguments

mtd

mtd info structure

chip

nand chip info structure

page

page number to read

sndcmd

flag whether to issue read command or not

nand_read_oob_syndrome

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_read_oob_syndrome` — [REPLACABLE] OOB data read function for HW ECC with syndromes

Synopsis

```
int nand_read_oob_syndrome (struct mtd_info * mtd, struct
nand_chip * chip, int page, int sndcmd);
```

Arguments

mtd

mtd info structure

chip

nand chip info structure

page

page number to read

sndcmd

flag whether to issue read command or not

nand_write_oob_std

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_write_oob_std` — [REPLACABLE] the most common OOB data write function

Synopsis

```
int nand_write_oob_std (struct mtd_info * mtd, struct
nand_chip * chip, int page);
```

Arguments

mtd

mtd info structure

chip

nand chip info structure

page

page number to write

nand_write_oob_syndrome

LINUX

Name

`nand_write_oob_syndrome` — [REPLACABLE] OOB data write function for HW ECC with syndrome - only for large page flash !

Synopsis

```
int nand_write_oob_syndrome (struct mtd_info * mtd, struct
nand_chip * chip, int page);
```

Arguments

`mtd`

mtd info structure

`chip`

nand chip info structure

`page`

page number to write

nand_do_read_oob

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_do_read_oob` — [Intern] NAND read out-of-band

Synopsis

```
int nand_do_read_oob (struct mtd_info * mtd, loff_t from,
struct mtd_oob_ops * ops);
```

Arguments

mtd

MTD device structure

from

offset to read from

ops

oob operations description structure

Description

NAND read out-of-band data from the spare area

nand_read_oob

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_read_oob` — [MTD Interface] NAND read data and/or out-of-band

Synopsis

```
int nand_read_oob (struct mtd_info * mtd, loff_t from, struct
mtd_oob_ops * ops);
```

Arguments

mtd

MTD device structure

from

offset to read from

ops

oob operation description structure

Description

NAND read data and/or out-of-band data

nand_write_page_raw

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_write_page_raw` — [Intern] raw page write function

Synopsis

```
void nand_write_page_raw (struct mtd_info * mtd, struct
nand_chip * chip, const uint8_t * buf);
```

Arguments

mtd

mtd info structure

chip

nand chip info structure

buf

data buffer

Description

Not for syndrome calculating ecc controllers, which use a special oob layout

nand_write_page_raw_syndrome

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_write_page_raw_syndrome` — [Intern] raw page write function

Synopsis

```
void nand_write_page_raw_syndrome (struct mtd_info * mtd,
struct nand_chip * chip, const uint8_t * buf);
```

Arguments

mtd

mtd info structure

chip

nand chip info structure

buf

data buffer

Description

We need a special oob layout and handling even when ECC isn't checked.

nand_write_page_swecc

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_write_page_swecc` — [REPLACABLE] software ecc based page write function

Synopsis

```
void nand_write_page_swecc (struct mtd_info * mtd, struct
nand_chip * chip, const uint8_t * buf);
```

Arguments

mtd

mtd info structure

chip

nand chip info structure

buf

data buffer

nand_write_page_hwecc

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_write_page_hwecc` — [REPLACABLE] hardware ecc based page write function

Synopsis

```
void nand_write_page_hwecc (struct mtd_info * mtd, struct
nand_chip * chip, const uint8_t * buf);
```

Arguments

mtd

mtd info structure

chip

nand chip info structure

buf

data buffer

nand_write_page_syndrome

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_write_page_syndrome` — [REPLACABLE] hardware ecc syndrom based page write

Synopsis

```
void nand_write_page_syndrome (struct mtd_info * mtd, struct
nand_chip * chip, const uint8_t * buf);
```

Arguments

mtd

mtd info structure

chip

nand chip info structure

buf

data buffer

Description

The hw generator calculates the error syndrome automatically. Therefor we need a special oob layout and handling.

nand_write_page

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_write_page` — [REPLACEABLE] write one page

Synopsis

```
int nand_write_page (struct mtd_info * mtd, struct nand_chip *
chip, const uint8_t * buf, int page, int cached, int raw);
```

Arguments

mtd

MTD device structure

chip

NAND chip descriptor

buf

the data to write

page

page number to write

cached

cached programming

raw

use _raw version of write_page

nand_fill_oob

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_fill_oob` — [Internal] Transfer client buffer to oob

Synopsis

```
uint8_t * nand_fill_oob (struct mtd_info * mtd, uint8_t * oob,
size_t len, struct mtd_oob_ops * ops);
```

Arguments

mtd

MTD device structure

oob

oob data buffer

len

oob data write length

ops

oob ops structure

nand_do_write_ops

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_do_write_ops` — [Internal] NAND write with ECC

Synopsis

```
int nand_do_write_ops (struct mtd_info * mtd, loff_t to,
struct mtd_oob_ops * ops);
```

Arguments

mtd

MTD device structure

to

offset to write to

ops

oob operations description structure

Description

NAND write with ECC

panic_nand_write

LINUX

Kernel Hackers ManualOctober 2026

Name

`panic_nand_write` — [MTD Interface] NAND write with ECC

Synopsis

```
int panic_nand_write (struct mtd_info * mtd, loff_t to, size_t
len, size_t * retlen, const uint8_t * buf);
```

Arguments

mtd

MTD device structure

to

offset to write to

len

number of bytes to write

retlen

pointer to variable to store the number of written bytes

buf

the data to write

Description

NAND write with ECC. Used when performing writes in interrupt context, this may for example be called by mtdoops when writing an oops while in panic.

nand_write

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_write` — [MTD Interface] NAND write with ECC

Synopsis

```
int nand_write (struct mtd_info * mtd, loff_t to, size_t len,
size_t * retlen, const uint8_t * buf);
```

Arguments

mtd

MTD device structure

to

offset to write to

len

number of bytes to write

retlen

pointer to variable to store the number of written bytes

buf

the data to write

Description

NAND write with ECC

nand_do_write_oob

LINUX

Name

`nand_do_write_oob` — [MTD Interface] NAND write out-of-band

Synopsis

```
int nand_do_write_oob (struct mtd_info * mtd, loff_t to,
struct mtd_oob_ops * ops);
```

Arguments

mtd

MTD device structure

to

offset to write to

ops

oob operation description structure

Description

NAND write out-of-band

nand_write_oob

LINUX

Name

`nand_write_oob` — [MTD Interface] NAND write data and/or out-of-band

Synopsis

```
int nand_write_oob (struct mtd_info * mtd, loff_t to, struct
mtd_oob_ops * ops);
```

Arguments

`mtd`

MTD device structure

`to`

offset to write to

`ops`

oob operation description structure

single_erase_cmd

LINUX

Name

`single_erase_cmd` — [GENERIC] NAND standard block erase command function

Synopsis

```
void single_erase_cmd (struct mtd_info * mtd, int page);
```

Arguments

mtd

MTD device structure

page

the page address of the block which will be erased

Description

Standard erase command for NAND chips

multi_erase_cmd

LINUX

Kernel Hackers ManualOctober 2026

Name

`multi_erase_cmd` — [GENERIC] AND specific block erase command function

Synopsis

```
void multi_erase_cmd (struct mtd_info * mtd, int page);
```

Arguments

mtd

MTD device structure

page

the page address of the block which will be erased

Description

AND multi block erase command function Erase 4 consecutive blocks

nand_erase

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_erase` — [MTD Interface] erase block(s)

Synopsis

```
int nand_erase (struct mtd_info * mtd, struct erase_info *
instr);
```

Arguments

mtd

MTD device structure

instr

erase instruction

Description

Erase one ore more blocks

nand_erase_nand

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_erase_nand` — [Internal] erase block(s)

Synopsis

```
int nand_erase_nand (struct mtd_info * mtd, struct erase_info
* instr, int allowbbt);
```

Arguments

mtd

MTD device structure

instr

erase instruction

allowbbt

allow erasing the bbt area

Description

Erase one ore more blocks

nand_sync

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_sync` — [MTD Interface] sync

Synopsis

```
void nand_sync (struct mtd_info * mtd);
```

Arguments

mtd

MTD device structure

Description

Sync is actually a wait for chip ready function

nand_block_isbad

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_block_isbad` — [MTD Interface] Check if block at offset is bad

Synopsis

```
int nand_block_isbad (struct mtd_info * mtd, loff_t offs);
```

Arguments

mtd

MTD device structure

offs

offset relative to mtd start

nand_block_markbad

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_block_markbad` — [MTD Interface] Mark block at the given offset as bad

Synopsis

```
int nand_block_markbad (struct mtd_info * mtd, loff_t ofs);
```

Arguments

mtd

MTD device structure

ofs

offset relative to mtd start

nand_suspend

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_suspend` — [MTD Interface] Suspend the NAND flash

Synopsis

```
int nand_suspend (struct mtd_info * mtd);
```

Arguments

mtd

MTD device structure

nand_resume

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_resume` — [MTD Interface] Resume the NAND flash

Synopsis

```
void nand_resume (struct mtd_info * mtd);
```

Arguments

mtd

MTD device structure

check_pattern

LINUX

Name

`check_pattern` — [GENERIC] check if a pattern is in the buffer

Synopsis

```
int check_pattern (uint8_t * buf, int len, int paglen, struct
nand_bbt_descr * td);
```

Arguments

buf

the buffer to search

len

the length of buffer to search

paglen

the pagelength

td

search pattern descriptor

Description

Check for a pattern at the given place. Used to search bad block tables and good / bad block identifiers. If the SCAN_EMPTY option is set then check, if all bytes except the pattern area contain 0xff

check_short_pattern

LINUX

Kernel Hackers ManualOctober 2026

Name

`check_short_pattern` — [GENERIC] check if a pattern is in the buffer

Synopsis

```
int check_short_pattern (uint8_t * buf, struct nand_bbt_descr
* td);
```

Arguments

buf

the buffer to search

td

search pattern descriptor

Description

Check for a pattern at the given place. Used to search bad block tables and good / bad block identifiers. Same as check_pattern, but no optional empty check

add_marker_len

LINUX

Name

`add_marker_len` — compute the length of the marker in data area

Synopsis

```
u32 add_marker_len (struct nand_bbt_descr * td);
```

Arguments

td

BBT descriptor used for computation

Description

The length will be 0 if the markeris located in OOB area.

read_bbt

LINUX

Name

`read_bbt` — [GENERIC] Read the bad block table starting from page

Synopsis

```
int read_bbt (struct mtd_info * mtd, uint8_t * buf, int page,
int num, struct nand_bbt_descr * td, int offs);
```

Arguments

mtd

MTD device structure

buf

temporary buffer

page

the starting page

num

the number of bbt descriptors to read

td

the bbt describtion table

offs

offset in the memory table

Description

Read the bad block table starting from page.

read_abs_bbt

LINUX

Name

`read_abs_bbt` — [GENERIC] Read the bad block table starting at a given page

Synopsis

```
int read_abs_bbt (struct mtd_info * mtd, uint8_t * buf, struct
nand_bbt_descr * td, int chip);
```

Arguments

mtd

MTD device structure

buf

temporary buffer

td

descriptor for the bad block table

chip

read the table for a specific chip, -1 read all chips. Applies only if NAND_BBT_PERCHIP option is set

Description

Read the bad block table for all chips starting at a given page We assume that the bbt bits are in consecutive order.

read_abs_bbts

LINUX

Kernel Hackers ManualOctober 2026

Name

`read_abs_bbts` — [GENERIC] Read the bad block table(s) for all chips starting at a given page

Synopsis

```
int read_abs_bbts (struct mtd_info * mtd, uint8_t * buf,
struct nand_bbt_descr * td, struct nand_bbt_descr * md);
```

Arguments

mtd

MTD device structure

buf

temporary buffer

td

descriptor for the bad block table

md

descriptor for the bad block table mirror

Description

Read the bad block table(s) for all chips starting at a given page We assume that the bbt bits are in consecutive order.

create_bbt

LINUX

Kernel Hackers ManualOctober 2026

Name

`create_bbt` — [GENERIC] Create a bad block table by scanning the device

Synopsis

```
int create_bbt (struct mtd_info * mtd, uint8_t * buf, struct
nand_bbt_descr * bd, int chip);
```

Arguments

mtd

MTD device structure

buf

temporary buffer

bd

descriptor for the good/bad block search pattern

chip

create the table for a specific chip, -1 read all chips. Applies only if NAND_BBT_PERCHIP option is set

Description

Create a bad block table by scanning the device for the given good/bad block identify pattern

search_bbt

LINUX

Kernel Hackers ManualOctober 2026

Name

`search_bbt` — [GENERIC] scan the device for a specific bad block table

Synopsis

```
int search_bbt (struct mtd_info * mtd, uint8_t * buf, struct
nand_bbt_descr * td);
```

Arguments

mtd

MTD device structure

buf

temporary buffer

td

descriptor for the bad block table

Description

Read the bad block table by searching for a given ident pattern. Search is preformed either from the beginning up or from the end of the device downwards. The search starts always at the start of a block. If the option NAND_BBT_PERCHIP is given, each chip is searched for a bbt, which contains the bad block information of this chip. This is necessary to provide support for certain DOC devices.

The bbt ident pattern resides in the oob area of the first page in a block.

search_read_bbts

LINUX

Kernel Hackers ManualOctober 2026

Name

`search_read_bbts` — [GENERIC] scan the device for bad block table(s)

Synopsis

```
int search_read_bbts (struct mtd_info * mtd, uint8_t * buf,
struct nand_bbt_descr * td, struct nand_bbt_descr * md);
```

Arguments

mtd

MTD device structure

buf

temporary buffer

td

descriptor for the bad block table

md

descriptor for the bad block table mirror

Description

Search and read the bad block table(s)

write_bbt

LINUX

Kernel Hackers ManualOctober 2026

Name

`write_bbt` — [GENERIC] (Re)write the bad block table

Synopsis

```
int write_bbt (struct mtd_info * mtd, uint8_t * buf, struct
nand_bbt_descr * td, struct nand_bbt_descr * md, int chipsel);
```

Arguments

mtd

MTD device structure

buf

temporary buffer

td

descriptor for the bad block table

md

descriptor for the bad block table mirror

chipsel

selector for a specific chip, -1 for all

Description

(Re)write the bad block table

nand_memory_bbt

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_memory_bbt` — [GENERIC] create a memory based bad block table

Synopsis

```
int nand_memory_bbt (struct mtd_info * mtd, struct
nand_bbt_descr * bd);
```

Arguments

mtd

MTD device structure

bd

descriptor for the good/bad block search pattern

Description

The function creates a memory based bbt by scanning the device for manufacturer / software marked good / bad blocks

check_create

LINUX

Kernel Hackers ManualOctober 2026

Name

`check_create` — [GENERIC] create and write bbt(s) if necessary

Synopsis

```
int check_create (struct mtd_info * mtd, uint8_t * buf, struct
nand_bbt_descr * bd);
```

Arguments

mtd

MTD device structure

buf

temporary buffer

bd

descriptor for the good/bad block search pattern

Description

The function checks the results of the previous call to read_bbt and creates / updates the bbt(s) if necessary Creation is necessary if no bbt was found for the chip/device Update is necessary if one of the tables is missing or the version nr. of one table is less than the other

mark_bbt_region

LINUX

Kernel Hackers ManualOctober 2026

Name

`mark_bbt_region` — [GENERIC] mark the bad block table regions

Synopsis

```
void mark_bbt_region (struct mtd_info * mtd, struct
nand_bbt_descr * td);
```

Arguments

mtd

MTD device structure

td

bad block table descriptor

Description

The bad block table regions are marked as “bad” to prevent accidental erasures / writes. The regions are identified by the mark 0x02.

verify_bbt_descr

LINUX

Name

`verify_bbt_descr` — verify the bad block description

Synopsis

```
void verify_bbt_descr (struct mtd_info * mtd, struct
nand_bbt_descr * bd);
```

Arguments

mtd

MTD device structure

bd

the table to verify

Description

This functions performs a few sanity checks on the bad block description table.

nand_update_bbt

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_update_bbt` — [NAND Interface] update bad block table(s)

Synopsis

```
int nand_update_bbt (struct mtd_info * mtd, loff_t offs);
```

Arguments

mtd

MTD device structure

offs

the offset of the newly marked block

Description

The function updates the bad block table(s)

nand_create_default_bbt_descr

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_create_default_bbt_descr` — [Internal] Creates a BBT descriptor structure

Synopsis

```
int nand_create_default_bbt_descr (struct nand_chip * this);
```

Arguments

this

NAND chip to create descriptor for

Description

This function allocates and initializes a nand_bbt_descr for BBM detection based on the properties of "this". The new descriptor is stored in this->badblock_pattern. Thus, this->badblock_pattern should be NULL when passed to this function.

nand_isbad_bbt

LINUX

Kernel Hackers ManualOctober 2026

Name

`nand_isbad_bbt` — [NAND Interface] Check if a block is bad

Synopsis

```
int nand_isbad_bbt (struct mtd_info * mtd, loff_t offs, int
allowbbt);
```

Arguments

mtd

MTD device structure

`offs`

offset in the device

`allowbbt`

allow access to bad block table region

Chapter 12. Credits

The following people have contributed to the NAND driver:

1. Steven J. Hill<sjhill@realitydiluted.com>
2. David Woodhouse<dwmw2@infradead.org>
3. Thomas Gleixner<tglx@linutronix.de>

A lot of users have provided bugfixes, improvements and helping hands for testing. Thanks a lot.

The following people have contributed to this document:

1. Thomas Gleixner<tglx@linutronix.de>